

COMMANDER XT1000 / XT2000 User Manual



COMMANDER XT1000 / XT2000 User Manual

Contents

ABOUT THE COMMANDER MOBILE COMPUTER	1
POWER MANAGEMENT	3
<i>Power Management-Conserving Battery Power</i>	<i>3</i>
<i>Screen Off Function</i>	<i>5</i>
<i>Backlight Off Delay Function</i>	<i>6</i>
<i>Backlight Brightness Adjustment Function</i>	<i>7</i>
RESETTING THE COMMANDER	8
<i>Resetting</i>	<i>8</i>
<i>To Soft Reset (or Warm Boot):</i>	<i>8</i>
<i>To Hard Reset (or Cold Boot):</i>	<i>8</i>
Wi-Fi / WLAN (802.11 a/b/g/n) RADIO	9
<i>Configuring the WLAN Radio</i>	<i>9</i>
CONTROLLING THE WI-FI, BLUETOOTH AND CELLULAR FUNCTIONS	13
COMMANDER PROGRAM	15
<i>Accessing the COMMANDER Program:</i>	<i>15</i>
CONFIGURING THE COMMANDER	19
<i>HOME / JOB Assignment Screen</i>	<i>19</i>
<i>Assigning the COMMANDER CLOUD Address</i>	<i>20</i>
<i>Updating the COMMANDER Databases</i>	<i>22</i>
<i>Pairing and Managing a Bluetooth Device</i>	<i>24</i>
<i>Setting the USER FILTER on the COMMANDER</i>	<i>23</i>
RETRIEVING JOBS ON THE COMMANDER	24
CREATING JOBS WITH THE COMMANDER	25
<i>Expert Assembly Method</i>	<i>26</i>
<i>Flange Assembly Method</i>	<i>29</i>
<i>Guided Assembly Method</i>	<i>33</i>
COLLECTING DATA WITH THE COMMANDER	36

CHANGING WRENCHES DURING A JOB	39
REVIEWING TORQUING CHARTS.....	41
ADDING A CHECK PASS.....	42
OUT OF SPECIFICATION READINGS	41
<i>Accepting an out of specification reading</i>	<i>41</i>
<i>Rejecting an out of specification reading</i>	<i>43</i>
OPTIONS.....	44
<i>Adding information to your report</i>	<i>44</i>
<i>Adding a picture to your report</i>	<i>45</i>
<i>Adding a comment to your report.....</i>	<i>46</i>
<i>Saving a Job Before Completion</i>	<i>47</i>
ERROR MESSAGES.....	48
COMMANDER XT2000 FUNCTIONALITY	50
TORQTAGS – Incorporating Them into Your Process	52
<i>Verifying the Bolting Sequence with TorqTags.....</i>	<i>53</i>
FREQUENTLY ASKED QUESTIONS	55

ABOUT THE COMMANDER MOBILE COMPUTER

Torq-Comm's COMMANDER XT1000 is a rugged IP65 sealed handheld PC for PRODUCTION CONTROL that provides up to the minute work instructions and bolting schematics to the operators in the field or factory. The work instructions are downloaded in real time to guide the operator through the entire assembly process while providing DATA COLLECTION during the bolting process.

This data, along with an unlimited amount of user-definable traceability information (such as operator, tool etc.), can then be stored on the Commander XT1000 or sent via Wi-Fi or cellular to a Cloud server immediately upon completion for remote storage and analysis. Equipment, materials and torqueing data for each bolt is automatically date & time stamped along with a GPS location. With front and rear facing high resolution cameras, barcode scanning with a 1D/2D imager or 1D laser scanner, as well as integrated RFID and NFC reading capabilities, Bluetooth, Wi-Fi, and 3G-4G cellular capability, almost all data collection scenarios are possible. Smart battery power management ensures you'll get through your busy day effortlessly.

The COMMANDER XT1000 survives repeated 5' drops to concrete across a wide operating temperature range, is sealed to IP65 standards and is UL 1604 Class 1 Div. 2 (A, B, C, D) certified to provide ultimate reliability and safety in extreme and hazardous locations.

CAUTION!

Do Not Use Tool Without Reading This First!

Before using any Torq-Comm tool, READ THIS MANUAL! Your safety, and the safety of others, may depend on your proper use of this tool. This manual provides information about the proper use of this tool that is important for your protection and for the protection of your work. If you don't understand any part of this manual ***do not use the tool***. Instead, seek assistance from your distributor or from Torq-Comm customer support.

Torque can be critical! Incorrect torque can be dangerous! Although Torq-Comm, Inc.'s tools are designed to be safe when used properly, improper use of these tools may create unsafe conditions resulting in catastrophic failures and other accidents, causing severe **injury** or **death**, significant property damage, expensive shut down of industry equipment or infrastructure, and environmental damage.

Understand torqueing specifications, conditions, and variables. The software embedded in this Torq-Comm tool makes preliminary torque calculations required for different applications based upon published specifications such as ASME PCC-1 2013, API flange specifications, ANSI material specifications, and other specifications that are common in the industry. Nonetheless, there are a number of variables that affect final torque calculations that must be properly accounted for when using this tool. These variables include, *but are not limited to*:

- design specifications for the work to which the tool is applied
- other information input by the tool user
- dirt or debris in a tapped hole
- grease or oil on the threads
- damaged threads
- hole misalignment

Don't ignore calibration and warnings. Your tool communicates with the digital pressure gauge and other components using wireless communications technology that must be properly calibrated and maintained. The digital pressure gauge is calibrated when it is shipped, but it is up to the user to re-calibrate it as required by the appropriate internal calibration schedule. Also, do not ignore or circumvent built-in safety features such as the requirement for supervisor approval of out-of-specification readings.

DISCLAIMER AND LIMITATION OF LIABILITY

EXCEPT FOR THE LIMITED PRODUCT WARRANTY PROVIDED WITH THE TOOL, THIS TOOL IS DELIVERED BY TORQ-COMM, INC., WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY WARRANTY OF DESIGN, ANY IMPLIED WARRANTY OF MERCHANTABILITY, ANY IMPLIED WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR FOR A GENERAL PURPOSE, AND ANY WARRANTY ARISING BY LAW OR STATUTE, COURSE OF DEALING, OR USAGE OF TRADE.

IN NO EVENT, REGARDLESS OF CAUSE, SHALL TORQ-COMM, INC., BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES OF ANY KIND, WHETHER ARISING UNDER BREACH OF CONTRACT, TORT, STRICT LIABILITY, PRODUCTS LIABILITY, OR OTHERWISE.

POWER MANAGEMENT

Power Management-Conserving Battery Power

COMMANDER XT1000 Series devices feature multiple power conservation options, some of which employ timers that can be set to strike a balance between user preference and optimal battery life.

On battery power timers control the selected action only when the device is being operated on battery power.

On external power timers control the selected action only when the device is being used with an external power supply.

 **Tip:** *Whenever practical, you can conserve battery life by:*

- 1. Using the AC adapter to plug the COMMANDER XT1000 Series device into an external power source.*
- 2. Manually or auto-suspend device operation as often as is practical*
- 3. Reduce the backlight brightness setting*
- 4. Turn off any wireless functionality (phone, Wi-Fi, Bluetooth or GPS) when not in use*

Main and backup battery status


1. Tap **SETTINGS** from the Windows Start desktop.



2. Tap **POWER**.



3. Main Battery and Backup Battery status are displayed in bar charts from 0% to 100%.



Screen Off Function

To adjust Screen Off function (device suspend mode):


1. Tap **SETTINGS** on the Windows **Start** desktop.



2. Tap **POWER** on the Windows Settings desktop.



3. Tap **Advanced** on the **Power**




4. Un-check **ON BATTERY POWER**.
5. Though this will use more power, there will be no interruption in the COMMANDER XT1000 program usage or data collection.
6. Un-check **ON EXTERNAL POWER**.
7. Repeat Step 5.
8. Tap **OK**

Backlight Off Delay Function

To adjust backlight off delay function:

1. Tap **SETTINGS** on the Windows **Start** desktop.



2. Tap **SYSTEM** folder on the Windows **Settings** desktop.



3. Tap **BACKLIGHT** on the Windows System desktop.



4. Check the **"Turn off the backlight if device not used for"** box and select the preferred length of inactivity before activation of the screen off power saving function from the pull-down menu. Shorter *off* delays will increase battery power conservation.

Backlight Brightness Adjustment Function

To adjust backlight brightness function:

1. Follow previous directions for Backlight Delay Function
2. Adjust the brightness level using the sliding bar in 20% increments. The Backlight will be turned off when the **Enable**



Backlight check box is disabled

Keypad backlight Enable and Duration To adjust keypad backlight duration function:

1. Tap **Settings** (icon) on the Windows **Start** desktop.
2. Tap **System** > **Backlight** (tab)> **Keypad backlight**
3. Enable the keypad backlight function by selecting the check box.

RESETTING THE COMMANDER

Resetting

In addition to on (Resume) and Off (Suspend) functions, COMMANDER XT1000 mobile computers provide a range of device reset (boot) procedures whose functions may be called upon when required.

IMPORTANT NOTE!

Some device reset options irretrievably delete stored user data! Always read and understand the parameters of selected reset procedures before execution.

On (Resume) / Off (Suspend) and Reset Functions

On (Resume) / Off (Suspend)

To Suspend or Resume COMMANDER XT1000 mobile computer operation:

- Press the **Red Power key** once to suspend operation and press again to resume.

Reset the COMMANDER XT1000

To Soft Reset (or Warm Boot):

A soft reset restarts the device and reboots the operating system. Applications and files remain intact. However, any data in RAM that has not been saved could be lost. Make sure to save any open work before executing a soft reset.

To perform a soft reset:

1. Press the Power button and hold for 3 seconds.
2. Choose 'Soft Reset' on the power menu.

To Hard Reset (or Cold Boot):

A hard reset, resets the hardware and cold starts the operating system. All applications and files remain but any unsaved data in RAM will be lost. Make sure to save all open work before executing a hard reset.

To perform a hard reset:

1. Press the Power button and hold for 3 seconds.
2. Choose 'Hard Reset' on the power menu.

Wi-Fi / WLAN (802.11 a/b/g/n) RADIO


The COMMANDER XT1000 has a 2.4 GHz and 5GHz **802.11 a/b/g/n** WLAN (Wireless Local Area Network) radio. The radio is interoperable with other 802.11a/b/g/n, Wi-Fi compliant products including wireless controllers, access points (APs), workstations via PC card adapters, and other wireless portable devices.

By default, the 802.11a/b/g/n radio is powered-off (i.e., disabled) "out of the box". Once enabled the state of the radio will survive subsequent soft and hard resets. The next step is to configure the connection parameters of the radio to connect to a wireless network.


Configuring the WLAN Radio

The WLAN radio is configured using the Portable Wireless Configuration Utility (PWC).

1. Tap **PWC**




2. Tap **Power On**



3. Tap the **CONFIG** tab at the bottom and **REFRESH** to identify the available Wi-Fi signals in your area.

If a SSID is already connected and indicated with a check mark in front of the name, first tap on that name and tap DISCONNECT. You are now free to choose another.




4. Tap the SSID you wish to connect with then tap **SETTING** to input the password.

5. Tap the PSK block and type in your PreShared Key or password.



Tap **OK** when complete.

6. Configuration is complete and accurate when the "Status" changes to "COMPLETED". The "Status" panel provides useful information about your wireless connection including the channel.



7. Tap **OK** when complete.




The IP tab shows your network configuration.


CONTROLLING THE WI-FI, BLUETOOTH AND CELLULAR FUNCTIONS

1. The Commander XT1000 has WI-FI, Bluetooth and Cellular communication capabilities that can be turned on or off from any screen or program.

First, tap the small icon bar at the top of the screen as shown below. It doesn't matter where you tap it.




2. A larger icon bar will drop down. Tap the Connectivity icon shown.



3. The Connectivity Window will appear. Tap the words **Wireless Manager**. It is a hyperlink to the Wireless Manager



4. From the Wireless Manager screen, you can turn On and Off each of the functions simply by tapping the Input Box. The function will toggle On and Off and the block fade or darken with each tap.




If the Commander is having trouble communicating to Pressure Gauge or Control Module, be sure Bluetooth is turned on.

If the Commander is having trouble communicating to the Commander Cloud in order to Update From Master or Retrieve Jobs, be sure the Wi-Fi or Phone are turned on.

COMMANDER PROGRAM

Accessing the COMMANDER Program:


1. Tap **Windows** (icon) from the Windows **Start** desktop.




2. Tap **Torq-Comm Vaetrix** (icon). This will open the COMMANDER XT1000 program.
3. Torq-Comm COMMANDER XT1000 welcome screen.




4. Tap the **USER NAME** block and select your user name from the drop down menu. (The System Administrator must first create a user name and password for each operator using the COMMANDER CLOUD system)
5. The downward arrow at the end of the Input Box indicates a drop down menu is available






Tap the option you wish to use to login.

6. Tap the **PASSWORD** block and type in your password.



The keyboard at the beginning of an Input Box indicates a virtual keyboard is available. The information can be typed using the keyboard on the COMMANDER or tapped in using the drop down keyboard and stylus.




7. Tap **LOGIN** to begin.

CONFIGURING THE COMMANDER


HOME / JOB Assignment Screen

1. The COMMANDER XT1000 must first be configured properly before it can be used. Downloading tool and program databases as well as torque assembly jobs can be easily completed and Bluetooth devices easily paired.




To begin, tap **SETTINGS** from the Home Screen.

2. From the **SETTINGS** screen, there are a number of options to configure your COMMANDER. Tap the **ADVANCED** tab to begin the set up.




Assigning the COMMANDER CLOUD Address

1. Tap the **WEB API ADDRESS** box and type the web address of your COMMANDER CLOUD system. This is unique to your organization and can be provided by your System Administrator. From this web address, the COMMANDER will be able to retrieve your torque assembly jobs and update your databases.



NOTE: It is imperative that the WEB API ADDRESS be correct for complete and proper communication to and from your COMMANDER CLOUD.

2. If you do not wish to automatically send torque assembly and traceability data to your COMMANDER CLOUD system, tap **ON** to toggle to **OFF**. Data will only be sent to your COMMANDER CLOUD when this is set to **ON**.



If you do not wish to require TorqTags to be used during the torque assembly jobs, tap ON to toggle to OFF. More information regarding TorqTags can be found in the Options Section of this document.

3. Tap **SAVE** to save your changes and updated settings and the **BACK** arrow to return to the previous screen.



Updating the COMMANDER Databases


1. Tap **UPDATE FROM MASTER** to down load the COMMANDER CLOUD system databases for Traceability, Wrenches, Equipment, Bolts and Flanges.


NOTE: You should update your handheld any time there are changes to any of your COMMANDER CLOUD databases. Without a complete and current database on your COMMANDER, it is possible you will not be able to complete torque assembly jobs if they require information not currently on your handheld.



Depending on your COMMANDER CLOUD database size and your transmission rate, an UPDATE FROM MASTER can take 2-4 minutes.

2. Tap **OK** when the completion screen appears.





3. Tap **SAVE** and tap the **BACK** arrow to return to the previous screen.

If the Commander is having trouble communicating to the Commander Cloud in order to Update From Master or Retrieve Jobs, be sure the Wi-Fi or Phone are turned on.

Refer to the CONTROLLING THE WI-FI, BLUETOOTH AND CELLULAR FUNCTIONS section on page 13 for complete instructions.


Pairing and Managing a Bluetooth Device

1. Pairing any Bluetooth device is very easy whether it is a Pressure Gauge, Pressure Transducer or Control Module.

Several devices of each type can be paired simultaneously but the COMMANDER XT1000 can only communicate with one Pressure device and one Control Module at a time.


Once paired, the device does not need to re-paired to initiate Bluetooth communication unless it is intentionally deleted from the COMMANDER XT1000.

2. Tap **PAIR DEVICES**.




3. Tap **REFRESH** to initiate a search for Bluetooth devices.

Devices as far away as 40 feet can be detected if there are no interferences.




4. The list of the available Bluetooth devices will appear. Tap the device you wish to pair with from the list and tap **PAIR**.




5. Type the device **PIN** to approve the communication with the device and provide a **DESCRIPTION** of the device for your future reference.

The description is for you to easily identify the different devices. The description can be alpha- numeric so a name or a serial number can be used.

Tap **NEXT** to complete pairing.




6. When the pairing is successful, a message box will display confirming the operation. Tap **OK**.




You can now pair another device, repeating steps 4 – 5, or tap **EXIT** to continue.

- From the Settings screen, tap **MANAGE DEVICES**, to select the Bluetooth device to use.



- From the list of paired Bluetooth devices, select the one you wish to communicate with. Tap **SET AS DEFAULT**. The Default will be set as TRUE. The COMMANDER XT1000 will now only communicate with this device.

Tap **CLOSE** to continue.




The Bluetooth device you wish to use can be changed for each job simply by selecting a different device and setting it as default. The Default will change from False to True for the new device.


Setting the USER FILTER on the COMMANDER

1. The COMMANDER XT1000 can be configured to display only the open torque assembly jobs assigned to the User who logged onto the device.

From the Settings Screen, tap **USER** to access this feature.



2. Tap the Filter Torque Assembly to toggle from ON to OFF.



In the ON setting, the COMMANDER will only display the open torque assembly jobs assigned to the User who logged onto the device.

In the OFF setting, the COMMANDER will display all of the open torque assembly jobs for an organization regardless of who logged onto the device.


RETRIEVING JOBS ON THE COMMANDER

1. From the Home Screen, tap RETRIEVE JOBS to download all of the open torque assembly jobs from the COMMANDER CLOUD.

NOTE: An active Wi-Fi or cellular connection is required to retrieve jobs.




2. Tap on the torque assembly job you wish to open and tap GO TO ASSEMBLY to begin the data collection.



CREATING JOBS WITH THE COMMANDER

You can create torqueing jobs on the COMMANDER XT1000 just as you can on the COMMANDER CLOUD. Step by step, either method is exactly the same using the same database of equipment and materials.

1. From the Home / Job Assignment screen, tap **ASSEMBLY**




2. You can select three different modes in creating your torqueing jobs.

Expert Assembly – the simplest method to enter existing jobs requiring the fewest inputs


Flange Assembly – creates jobs based on the pipe size and the working pressure of the fluid inside

Guided Assembly – creates jobs based on the number / size of the bolts and percent yield



Expert Assembly Method

1. Tap **EXPERT** to begin




1. Enter the required Traceability information.


The Traceability information can be inputted in a number of different ways depending how the System Administrator configured the blocks.

The information can be inputted by typing, picking from a drop down menu or barcode scanning.

Tap **NEXT** when complete.




2. Enter the number of bolts, passes, torque wrench, sequence type and the required final torque. The drop down menus can be accessed by tapping on each block.



A screenshot of the Commander XT1000 / XT2000 app interface. The screen displays five input fields stacked vertically: 'NUMBER OF BOLTS', 'PASSES', 'TORQUE WRENCH', 'SEQUENCE TYPE', and 'TORQUE FT-LB'. Each field has a corresponding input box. The 'TORQUE WRENCH' and 'SEQUENCE TYPE' fields have small downward arrows indicating they are dropdown menus. The status bar at the top shows the time as 8:34.


3. Tap **CALCULATE** to determine the required final pressure.



A screenshot of the Commander XT1000 / XT2000 app interface. The screen displays the 'SEQUENCE TYPE' dropdown menu set to 'Star', the 'TORQUE FT-LB' input field set to '3000', and the 'PRESSURE' output field showing '1,518'. The 'Calculate' button is highlighted with a yellow circle. The bottom navigation bar shows 'Home', 'Expert', and 'Next' (with a right arrow icon). The status bar at the top shows the time as 8:37.

Tap **NEXT**


4. The COMMANDER XT1000 will review the information for accuracy and present the bolting sequence based on the number of bolts and the sequence type. It will present Valid Sequence if correct.



5. Tap **NEXT** to begin the data collection.

Flange Assembly Method


1. Tap **FLANGE ASSEMBLY** to begin



2. Enter the required Traceability information.


The Traceability information can be inputted in a number of different ways depending how the System Administrator configured the blocks.

The information can be inputted by typing, picking from a drop down menu or barcode scanning.




Tap **NEXT** when complete.


3. Tap the Pipe Diameter block to access the pull down menu. Select the appropriate size.
4. Tap the Working Pressure block to access the appropriate pressure for that Pipe Diameter.



5. Tap **NEXT** to continue.
6. Enter the number of bolts, bolt diameter, thread pitch, lubricant. The drop down menus can be accessed by tapping on each block.




7. Enter the bolt material, bolt tension, torque wrench, sequence type and number of passes. The drop down menus can be accessed by tapping on each block.




A screenshot of the COMMANDER XT1000 / XT2000 app interface. The screen displays five input fields with labels: "BOLT MATERIAL", "BOLT TENSION lb", "TORQUE WRENCH", "SEQUENCE TYPE", and "PASSES". Each field has a dropdown arrow on the right. The "PASSES" field is currently set to "3". At the bottom, there is a navigation bar with a home icon labeled "Home" and a button labeled "Flange".

Tap **CALCULATE** to determine the percent yield, final pressure and final torque.



A screenshot of the COMMANDER XT1000 / XT2000 app interface showing the results of a calculation. The "Calculate" button is highlighted with a yellow circle. Below the button, the results are displayed: "PERCENT YIELD" is 49.68, "PRESSURE PSI" is 886, and "TORQUE ftlb" is 1,750. At the bottom, there is a navigation bar with a home icon labeled "Home", a button labeled "Flange", and a right arrow icon labeled "Next".


8. The COMMANDER XT1000 will review the information for accuracy and present the bolting sequence based on the number of bolts and the sequence type. It will present Valid Sequence if correct.



9. Tap **NEXT** to begin the torqueing job.

Guided Assembly Method


1. Tap **GUIDED ASSEMBLY** to begin



2. Enter the required Traceability information.

The Traceability information can be inputted in a number of different ways depending how the System Administrator configured the blocks.

The information can be inputted by typing, picking from a drop down menu or barcode scanning.



Tap **NEXT** when complete.


3. Enter the number of bolts, bolt diameter, thread pitch, lubricant. The drop down menus can be accessed by tapping on each block.

A screenshot of a mobile application interface with a black background and white text. At the top, there is a status bar with various icons and the time 8:40. The main content area contains four input blocks: 'NUMBER OF BOLTS' with a text field containing '16' and a clear button; 'Bolt Diameter (in)' with a dropdown menu showing '1-3/4'; 'Threads per inch' with a dropdown menu showing '5'; and 'LUBRICANT' with a dropdown menu showing 'Moly / Lead Oxide / Gra'. A yellow rectangular box highlights the 'LUBRICANT' dropdown menu. At the bottom, there is a navigation bar with a home icon and the text 'Home', and a button labeled 'Flange'.


4. Enter the bolt material, bolt tension, torque wrench, sequence type and number of passes. The drop down menus can be accessed by tapping on each block.

A screenshot of a mobile application interface with a black background and white text. At the top, there is a status bar with various icons and the time 8:41. The main content area contains five input blocks: 'BOLT MATERIAL' with a dropdown menu; 'BOLT TENSION lb' with a text field; 'TORQUE WRENCH' with a dropdown menu; 'SEQUENCE TYPE' with a dropdown menu; and 'PASSES' with a text field. At the bottom, there is a navigation bar with a home icon and the text 'Home', and a button labeled 'Flange'.

5. Tap **CALCULATE** to determine the percent yield, final pressure and final torque.



6. The COMMANDER XT1000 will review the information for accuracy and present the bolting sequence based on the number of bolts and the sequence type. It will present Valid Sequence if correct.




7. Tap **NEXT** to begin the torquing job.

COLLECTING DATA WITH THE COMMANDER

The Home Screen / Job Assignment screen will show the jobs assigned to a particular operator.

1. Select the job to be complete. Then tap **GO TO ASSEMBLY**.



2. The Job Summary screen will give an overview of the job outlining the materials and equipment required.

Tap **CONTINUE**.



3. Enter the required Traceability information.


The Traceability information can be inputted in a number of different ways depending how the System Administrator configured the blocks.

The information can be inputted by typing, picking from a drop down menu or barcode scanning.

Tap **NEXT** when complete.


The screenshot shows a mobile application interface for data entry. At the top, there's a status bar with icons and the time 8:09. Below it, the title 'Customer' is followed by a dropdown menu. Then, there are three text input fields labeled 'Flange Serial Number', 'Valve Serial Number', and 'Supervisor'. At the bottom, there's a navigation bar with three buttons: 'Home' (with a house icon), 'Traceability' (with a right arrow icon), and 'Next' (with a right arrow icon). The 'Next' button is highlighted with a yellow circle.

4. The Collection screen tells which pass you are on, which bolt is to be tightened as well as the torque wrench to be used and the pump pressure setting.




Tap **START** to begin collecting data.

- The Data screen shows the information received for a particular tightening sequence. The pass and bolt number are displayed on top. Additional data such as the date and time of the tightening are recorded as is the temperature of the pump fluid. The target pressure, maximum pressure and the current pressure are displayed. The maximum pressure for each bolt is displayed in the resulting graphs. Tap **DONE** when the tightening sequence is complete.



- The Collection screen will highlight the next bolt to be tightened. The current bolt is highlighted in **RED** and the completed bolts are highlighted in **GREEN**. Tap **START** to begin the next bolting sequence.




Tap **SKIP** to move to skip this bolt and move to the next bolt in the sequence. Continue, repeating steps 4-5, until all bolts are tightened for each pass.

CHANGING WRENCHES DURING A JOB


The COMMANDER allows the Torque Wrench to be exchanged at any time during a torque assembly job quickly and easily without losing data or traceability.

The new torque and target pressure will be calculated and shown. The Traceability information will be updated with the new Torque Wrench and parameters.


1. The Bolt Pattern screen shows the pass, the current bolt number, the target pressure as well as the Torque Wrench in use.




2. By tapping on the Torque Wrench Input Box, a drop down menu of all of the available Torque Wrenches will appear. Scroll through the list and select the correct one.



3. The new Torque Wrench can quickly be identified by inputting the Torque Wrench serial number if available. This can be done by scanning a barcode label on the Torque Wrench or typing in the number. Tap on the Barcode symbol as shown.



4. Tap on the Serial Number Input Box. You can scan the barcode label on the tool using one of the three orange buttons on the COMMANDER or type the number by hand. Tap **OK** to continue.




Note: The COMMANDER will warn the operator if the target pressure is outside the range of the Torque Wrench selected and will not permit them to continue until a suitable wrench is selected.


REVIEWING TORQUING CHARTS

At any time during the torquing job, you can review your progress by monitoring the charts. The chart provides the bolting data for each bolt completed.

1. Tap **CHART**




The torque or the pressure data can be displayed for the vertical axis. Simply tap the screen to toggle between the two.




ADDING A CHECK PASS

1. After the required passes are complete, the COMMANDER XT1000 will ask if you would like to perform a check pass. Tap either YES to perform a check pass or NO to complete and close the tightening job.



2. Tap the SELECT SEQUENCE TYPE block to select a sequence from the drop down menu and tap **NEXT**. The default is CIRCLE based on ASME PCC-1 2013.




The program will walk you through an additional pass according to the previous section. When that pass is completed, it will again ask if you will like to perform a check pass. It will continue this until **NO** is selected.

OUT OF SPECIFICATION READINGS

1. If the pump is set improperly, it is possible to obtain pressure readings outside the tolerance for the target pressure. A message will appear alerting you to this fact.


Tap OK to continue.




Accepting an out of specification reading

1. It is possible to accept the out of specification reading with a Supervisor's approval.

After tapping OK to the Alert, the Authorization screen appears. A Supervisor must enter a pre-assigned four-digit PIN in order to accept the out of specification. After typing in the PIN, tap AUTHORIZE PIN.




2. Upon authorizing the out of specification reading, the Supervisor is given the opportunity to add a comment. The comments can be predetermined and available in the drop down menu or typed to add alternates by selecting OTHER REASON. The comment will be included in the bolting data.
3. Tap OK to accept and return to the tightening screen.




Rejecting an out of specification reading

1. If it is not desired to accept the out of specification reading, simply tap the CANCEL tab.



2. Once the reading is rejected, you will be taken to the tightening screen. Tap RE-TIGHTEN BOLT.


The out of specification reading will be noted in the bolting data but not displayed in the graph. The re-tightened reading will be noted in the bolting data and displayed in the graph.




OPTIONS

Adding information to your report

1. At any time, you can add additional information to your bolting report in the form of text comments or pictures.
2. Simply tap the **OPTIONS** tab.



1. Tap **TAKE A PICTURE** or **ADD A COMMENT**.




2. At any time, you can go back to the Collection screen by tapping **COLLECT**.

Adding a picture to your report

1. The COMMANDER XT1000 has a high-resolution camera capable of amazing clarity.

Tap **TAKE PICTURE** from the OPTIONS screen. Tap **TAKE A PICTURE**.




2. Tap the **KEYBOARD ICON** to show the keyboard. Tap the **CARRIAGE RETURN (CR)** to take the picture.



Adding a comment to your report

1. Tap **ADD COMMENT** from the Options page. Tap the ADD COMMENT block to pull down the preselected options or type in another.


Tap **SUBMIT** to accept the comment. Tap **BACK** to return to the Option screen.



Saving a Job Before Completion


1. At any time during the bolting procedure, you can stop the job and save your data.

Simply tap **HOME**.



2. The program will ask if you want to save your progress and go Home. Your work will be saved and you will return to your point where you stopped.


Tap **YES** to close the job and return Home.




ERROR MESSAGES

1. If the Percent Yield is above 60%, the system will warn you but allow you to proceed.

Tap **OK** to proceed.




2. After tapping OK to the Alert, the Authorization screen appears. A Supervisor must enter a pre-assigned four-digit PIN in order to accept the out of specification. After typing in the PIN, tap AUTHORIZE PIN.




Tap **CANCEL** to return to the input screens.

3. If the resulting pressure is below the minimum recommended by the wrench manufacturer, the system will present a warning message. However, tapping **OK** will allow you to proceed should you choose.



4. If the resulting torque is above the recommended torque by the wrench manufacturer, the system will present a warning message. It will not allow you to proceed.




Tapping **OK** will take you to the previous screen to adjust the values or tools.

COMMANDER XT2000 FUNCTIONALITY


The COMMANDER XT2000 delivers all of the that the COMMANDER XT1000 provides plus the ability to adjust the pressure of the hydraulic or pneumatic pump from up to 40 feet away when fitted with a COMMANDER CONTROL MODULE.

This section will highlight only the unique features of the COMANNDER XT2000.

1. The COMMANDER XT2000 allows a User with Supervisor or higher privileges to adjust the pump pressure. From the Home screen, tap **PRESSURE** to begin.




2. Tap the Pressure Setting Input Box. Type in the required pressure and tap **ADJUST**.



The Pump Pressure will be adjusted automatically. When the pressure is reached, tap **HOME**

NOTE: The pump needs to be at pressure and stabilized before the ADJUST button is tapped. This provides the correct starting point for the pump adjustment and allows the COMMANDER to calculate the direction and amount to adjust the pump pressure. Not having the pump at pressure or stabilized may increase the time to complete the adjustment.

3. Prior to collecting data during a torque assembly job, the COMMANDER XT2000 will inform the Operator of the required target pressure based on the pass. The Operator simply taps **ADJUST** to set the pressure up to 40 feet away.



The Pump Pressure will be adjusted automatically.

4. Prior to the start of subsequent passes, the operator will receive similar screens informing them of the new target pressure. The Operator simply taps **ADJUST** to set the pressure.

The Pump Pressure will be adjusted automatically.

NOTE: The pump needs to be at pressure and stabilized before the ADJUST button is tapped. This provides the correct starting point for the pump adjustment and allows the COMMANDER to calculate the direction and amount to adjust the pump pressure. Not having the pump at pressure or stabilized may increase the time to complete the adjustment.

TORQTAGS – Incorporating Them into Your Process


TorqTags are a quick and convenient method of numbering the bolts on a flange. No longer are chalk or paint pens needed. Rather this reusable magnetic disc can be used with the number and barcode clearly visible and able to be scanned by the COMMANDER XT1000.



The TorqTags are placed on the bolt or the flange according to your bolting pattern as shown below.




The TorqTag is scanned with the COMMANDER prior to torqueing to ensure the wrench is on the correct bolt.



Verifying the Bolting Sequence with TorqTags

1. Using TorqTags with the COMMANDER system is easy and seamless. After the Traceability information is imputed in a torque assembly job, and prior to the torquing data being collected, the COMMANDER will require a barcode scan of the TorqTag on the bolt to be tightened.



The COMMANDER tells you the correct bolt number in the sequence and compares the barcode scan to verify the wrench placement.

2. By pushing one of the three Orange buttons on the COMMANDER, the system will read

the barcode on the TorqTag.



3. If the TorqTag does not match the bolt sequence, you will be instructed to move the wrench to the correct location.
When the numbers match, you will be taken to the Bolting Sequence screen.

FREQUENTLY ASKED QUESTIONS

1. **What is the XT1000?** – It is a rugged IP65, handheld PC that provides data COLLECTION during the bolting process.
2. **What is the XT2000?** – It is an XT1000 plus a pump mounted assembly that wirelessly provides pressure CONTROL of the pump during the bolting process.
3. **Is Torq-Comm sold elsewhere as an OEM product?** - The Commander XT's and related products are available only through Torq-Comm's distribution channels at this time.
4. **Does Torq-Comm compete with GaugeFlex?** - The GaugeFlex system is designed for Quality Control data collection while the Torq-Comm products are designed for production and assembly data collection.
5. **Do the Torq-Comm Commander XT'S provide an error-proof system?** – Unfortunately, as long as humans are involved, there will always be the possibility of errors. Robots may be the only way to accomplish this. You can set most any gauge to the desired reading and press enter. Operator integrity is crucial, however, the Torq-Comm products greatly reduce the chances of operator error. Besides this, it is ten times better than what they are doing currently.
6. **Can I over-torque?** - By combining our collect and control capabilities with the XT2000, a supervisor can create a work instruction that specifies the correct pressure settings and be confident those settings will be unchanged. With our ability to limit the access certain operators have, we can automatically set the pressure settings and prevent operators from changing them.
7. **How can the Commander XT'S prevent rehits?** – With the XT2000, we can control the pump's pressure. Operators without privileges cannot increase the pressure past predetermined points. Hence, if they attempt to increase pressure, even accidentally, the system will not allow it.
8. **Are the Commander XT'S explosion proof?** - These units are Class 1 Div. 2 rated for explosive environments. Should you need Class 1 Div. 1 we have other units to satisfy these needs.
9. **How can I insure assembly integrity through the use of bolting patterns?** - The Commander XT'S are developed according to ASME specifications for flange assembly. Bolting patterns are included in the Commander XT's software. By following the instructions displayed on the screen, we can walk the operator through tightening each bolt of each pass of the assembly procedure, all the while collecting the necessary data to ensure traceability.
10. **Can I ensure the tool is being placed on the right bolt?** – Hopefully! We are currently working with the Rochester Institute of Technology to ensure the bolting pattern is followed. Should the operator place the tool on the wrong bolt, the pump will not be allowed to activate.

11. **Does it possess the ability of measuring angular rotation?** – Without a transducer and gyroscope installed on the wrench, we cannot measure angular rotation. However, with pumps that possess flow meters with output, we can measure and correlate flow to rotation. Similarly, if the pump has an ammeter with output, we can see when the pump is under load (rotation) and not.
12. **What if there is no Wi-Fi access?** - If you're out in the field and away from a Wi-Fi connection, the Commander XT's can utilize its on-board cellular capability to send data. When neither Wi-Fi nor cellular are available, you can retain the data to the Commander XT'S internal SD card, until which time either Wi-Fi or cellular connectivity returns. It will then automatically send all unsent data.
13. **Can I note defects observed?** - The Commander XT'S are capable of collecting any type of attribute data. Unlimited text comments can be included in each set of data. With the high resolution built-in camera, detailed pictures of the defects can be easily captured and stored.
14. **Can I enter traceability data?** - Traceability is key to understanding the quality of the assembly procedure and being able monitor changes over time. The number of traceability fields for a particular assembly is unlimited and is configurable by each user. Standard traceability fields are operator, flange serial #, GPS location, tool, etc., and are entered by pick list, barcode or keyboard.
15. **Can we send alerts in the event of a problem?** - Email, text or cell phone alerts can be sent if an error occurs either in the assembly or in the tools calibration. Torq-Comm takes the decision making out of the operator's hands and places it back into the supervisor's hands to provide real time decisions.
16. **Must I store my data to a cloud?** – You can transmit directly a local PC or server should you wish to keep the data in house.
17. **Whose pump does this work with?** - By incorporating a Bluetooth pressure gauge, the Commander XT'S can interface with most manufacturers' pump in order to collect the necessary assembly data. Optional mounting kits will be available according to the pump being used.
18. **Can I collect data that is not circular in nature like a flange?** - With an optional design module, you can create unique, non-circular assembly procedures for your assembly control.
19. **Is it unique?** – Torq-Comm has a patent pending on this technology. Other competitors have data collection methods, but nothing as sophisticated and innovative as the mobile Commander XT'S.